## MOOG® Complete Knuckle Assembly

Easy to Install - Saves up to 1.5 hours in time

The new MOOG® Complete Knuckle Assembly is designed to make troublesome bearing replacement easier. The pre-assembled part eliminates the need for special tools or a press, resulting in easier installation and time savings of up to 50%.

In addition, it saves the time required to locate and source multiple parts.

Pre-assembled unit includes application-specific, premium components:





moogparts.com

#partsmatter



## MOOG® Complete Knuckle Assembly Applications

PART #	PLACEMENT	APPLICATION
LK001	Left Rear	Ford Explorer 3/4/2002-02, 17mm Tie Rod Stud Diameter* Ford Explorer 2003-05* Mercury Mountaineer 3/4/2002-02, 17mm Tie Rod Stud Diameter* Mercury Mountaineer 2003-05*
LK002	Right Rear	Ford Explorer 3/4/2002-02, 17mm Tie Rod Stud Diameter* Ford Explorer 2003-05* Mercury Mountaineer 3/4/2002-02, 17mm Tie Rod Stud Diameter* Mercury Mountaineer 2003-05*
LK003	Left Front	Ford Focus 2006-11
LK004	Right Front	Ford Focus 2006-11
LK005	Left Front	Nissan Altima 2002-06 (2.5L, 27 splines)
LK006	Right Front	Nissan Altima 2002-06 (2.5L, 27 splines)
LK007	Left Front	Volkswagen Beetle 1998-10 Volkswagen Golf 2010 1984cc (2.0L), 7th and 8th Digit of Vin is BE Volkswagen Golf 2000-09 Volkswagen Golf 1999, 7th and 8th Digit of Vin is 1J Volkswagen GTI 1999-02 Volkswagen Jetta 2005-06, 7th and 8th Digit of Vin is 9M or 1J Volkswagen Jetta 2000-04 Volkswagen Jetta 1999, 7th and 8th Digit of Vin is 9M or 1J
LK008	Right Front	Volkswagen Beetle 1998-10 Volkswagen Golf 2010 1984cc (2.0L), 7th and 8th Digit of Vin is BE Volkswagen Golf 2000-09 Volkswagen Golf 1999, 7th and 8th Digit of Vin is 1J Volkswagen GTI 1999-02 Volkswagen Jetta 2005-06, 7th and 8th Digit of Vin is 9M or 1J Volkswagen Jetta 2000-04 Volkswagen Jetta 1999, 7th and 8th Digit of Vin is 9M or 1J
LK009	Left Front	Nissan Altima 2002-06 (3.5L V6, 3498cc, 29 splines) Nissan Maxima 2004-08, 29 splines
LK010	Right Front	Nissan Altima 2002-06 (3.5L V6, 3498cc, 29 splines) Nissan Maxima 2004-08, 29 splines

\*Prior to installing the MOOG Complete Knuckle Assembly on this vehicle, inspection of the parking brake shoes and hardware is recommended. If parking brake shoes require replacement, the following Wagner® brake components are available:

Parking Brakes Shoe Set Application

Z745 Ford Explorer 2 Door 2002-03 Z791 Ford Explorer 4 Door 2002-10

Hardware Kit Application

H7240 Ford Explorer 2002-11



For parts lookup, visit: www.fme-cat.com Tech line: 1-800-325-8886

moogparts.com #partsmatter



